

ASSEMBLY INSTRUCTIONS


STEEL PLANED OUTDOOR FIREPLACE

terrain

OUTDOOR USE ONLY!!


Do Not use under low tree limbs
Do Not use near walls
Do Not use near Shrubs or Bushes
Do Not overfill with wood
Do Not leave fire unattended
Do Not burn fires near flammable materials
Do Not clean with harsh chemicals
Do Not allow children and pets near the
Fireplace without supervision.
Do Not touch the hot surfaces
Do Not use water to extinguish fire as it can
damage Fireplace
Do Not place Fireplace on wood surfaces

Do Clean the Fireplace after every use
Do Check the weather before lighting a fire
Do Check local fire laws
Do Blot spills with a clean towel
Before cleaning test a small spot
Use only untreated wood and logs




Assemble all parts on a clean smooth surface
Do not throw away packing materials and carton until after assembly.


PARTS INCLUDED




(A) Body 1x



(B) Cap 1x





(C) Bolt 8x M6*10mm



(D) Hex key 1x

1. Place Fireplace Body (A) outdoors away from any walls and away from Bushes and shrubs. Do not place Fireplace under low tree limbs. Align the Cap (B) onto the top of the Body (A). Insert Bolt (C). Once all Bolts (C) are inserted then completely tighten the Bolts (C) with supplied Hex Key (D). Slide Ash Tray forward to clean.



EXCLUSIVE AND CONFIDENTIAL PROPERTY OF URBAN OUTFITTERS, INC.

© 2017 UO, Inc. All rights reserved, including all applicable copyright, design and patent rights. Any unauthorized reproduction, adaptation, distribution or other infringement will be